TYPE MK6 BOMB HOIST B.O.284441 (REF)

28W5005 (REF) WING CONTOUR

HOIST CABLE

REMOVE HOIST PIN & HOIST CABLE AFTER LATCHES ARE LOCKED & LOCKPIN ASSYS ARE IN PLACE.


B.O.328758 MK51-7 (REF) BOMB RACK

LATCH TRIGGERS

28A5200 CHOCK (REF)

28A5191 LOCKPIN ASSYS (REF)

VIEW OF BOMB IN PLACE



VIEW OF BOMB BEING HOISTED

H 51

NOTES:

1. FOR INTERNAL ADAPTER ARRANGEMENT SEE DWG. 28A6202
2. FOR EXTERNAL ADAPTER ARRANGEMENT SEE DWG 28A5201
3. HOISTING OPERATIONS ARE THE SAME FOR INTERNAL & EXTERNAL BOMB RACKS.

APPROVED FOR TOOLING BY RB HUMPHREYS 1-2-43

MCR126-8

PART No.	STOCK	MATERIAL	SPEC.

PARTS LIST FOR ASSY.

-0 -2 -3 -4 -5

MODEL	B4Y-3
NEXT ASSY	28B1058
SCALE	NONE
A6	
HEAT TREAT	NONE
FINISH	NONE

HOISTING INSTRUCTIONS - ARMT - BRITISH BOMB ADAPTER

CONSOLIDATED AIRCRAFT CORP. SAN DIEGO, CALIF.

J 28A5207